How to disable the second head of a dual head IRIX system

Published 02/03/2012

Symptom(s):

How to disable the second head of a dual head IRIX system

Fact(s):

IRIX 6.5
Silicon Graphics Octane
Silicon Graphics Onyx2
Silicon Graphics Tezro
Silicon Graphics Octane 2
Silicon Graphics Onyx3
Xsgi

SGI Solution:

The file /var/X11/xdm/Xservers usually controls which servers are started and options to the Xsgi X server control which keyboard/mouse or other input devices are used.

In the following example, 2 X servers are started. The first on graphics board 0, and using device directory /dev/input (where the character device files for the primary keyboard and mouse will be).
The second uses board 1 and device files from /dev/input1.

```
:0 secure /usr/bin/X11/X :0 -boards 0 -devdir /dev/input -bs
:1 secure /usr/bin/X11/X :1 -boards 1 -devdir /dev/input1 -bs
```

To avoid starting a particular head, simply comment out the appropriate line and reboot, or restart xdm with

```
# /usr/gfx/stopgfx
# /usr/gfx/startgfx
```

Additional Details

Creation Date	01/18/2012 04:18 AM
Last modification	09/20/2015 03:56 PM
Published Date	02/03/2012
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Software • Legacy Software • Operating Systems • IRIX • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • How To/Question